# REFERENCE SS8/SS 1 OR/SS12R Subwoofers

INSTALLATION GUIDE



SOUNDSTREAM TECHNOLOGIES

120 Blue Ravine Road • Folsom • California 95630 USA te1916.351.1288 fax 916.351.0414

rev B-5.20.94



## REFERENCE SUBWOOFERS

## **CONGRATULATIONS!**

You have chosen a superior product for reproducing true high-fidelity in the car. This precision component, when properly installed, is capable of audiophile-quality performance. The REFERENCE woofers are well-suited for sealed, vented, and bandpass enclosures. They also work well in infinite baffle installations at one-half the power rating.

Should your woofer ever require service or replacement, recording the information below for your own records will help protect your investment.

odel Number:
rial Number:
ealer's Name:
te of Purchase:
stalla tion Shop:
stallation Date:

#### DESIGN FEATURES •

- Installation Flexibility The REFERENCE woofers perform well in infinite baffle, sealed, vented, and bandpass enclosures. Regardless of the application, REFERENCE woofers perform.
- Long Excursion Design The REFERENCE woofers use high performance components to achieve extra long excursion for high output deep bass.
- Massive Double Magnet Structure for precise impact and deep bass.
- Custom-designed High Strength Spider controls the long travel cone assembly.
- Custom-designed Cast Frame Basket for deep excursion and precise alignment of the voice coil.
- Computer Numerically Controlled machined magnet plates precisely focus the magnet energy for optimum performance.
- Designed and Manufactured in the U.S.A.

THIELE	E/SMALL	PARAMETERS	
	SS-8	SS-1 OR	SS-1 2R
Freq. Response	40-500 Hz	32-500 Hz	33-500 Hz
Sens. 1w/1m	90 dB	90 dB	92 dB
Impedance (nom. z)	4 ohns	4 ohms	4 ohms
Rated Program Power	100 watts	200 watts	200 watts
Rated Peak Power	200 watts	300watts	400watts
Fs	40 Hz	35 Hz	35 Hz
Qts	0.370	0. 376	0. 476
Qms	2.16	8.8	8. 475
Qes	0.450	0. 393	0. 504
Vas (ft3)	1.06	1.80	4.00
Vas (liters)	30	51.0	113. 3
Vas (m3)	0.030	0. 051	0. 113
Cms (um/N)	416	329. 8	283
DCR (ohms)	4. 4	3. 36	3.74
Levc (mH) @ 1 kHz	0. 95	1. 05	1. 332
BL (Tesla m)	9. 6	10.75	10. 897
Sd (in')	34. 8	54. 3	86. 7
Sd (m2)	0. 0220	0. 0350	0.0531
Sd (cm2)	220	, 350	531
X max one way (linear mm)	7. 00	6. 6	7. 5
X max			
one way (peak mm)	17	22	25
Vd (linear cm3)	157	231	398
Vd (peak cm3)	380	770	1325
Vd (linear m3)	0.000157	0.000231	0. 000398
Vd (peak m3)	0.000380	0. 000770	0. 001325
Mms (grams)	37.6	60	68
Magnet Assembly (oz)	88	180	195
Magnet Weight (oz)	40	86	86
Vf (volume of frame)	50i n3	180i n3	200 in3
Coil (mm)	17	22.7	22.0
TP (mm)	8	9. 5	9. 5
Mounting Dia. (in)	<b>7</b> 'It)	<b>9</b> 'I,	11 'I*

THIFLE/SMALL PARAMETERS

### SELECTING AN ENCLOSURE

There are several different enclosure designs for different applications. The REFERENCE subwoofers work very well in all the following enclosure designs. it is up to you to select the specific enclosure that will work the best for your particular application.

#### Infinite Baffle

Infinite baffle is the simplest type of subwoofer installation. In this type of installation, the woofer(s) is mounted to a baffle which is then mounted to either the rear deck or back seat of the vehicle. The best results are achieved when the trunk area is virtually airtight and isolated from the passenger compartment.

Pros

@Excellent low frequency extension

\*Excellent transient response Uses almost no trunk space

Cons

Lower power handling

Low to medium efficiency

#### **Sealed Enclosure**

Sealed enclosures are relatively simple to build and install, as all that is required is an airtight box. The larger the sealed enclosure, the more the performance resembles that of an infinite baffle installation. Small sealed enclosures work very well in midbass applications.



Pros Cons

Very good low frequency extension

Very good transient

Medium power handling

Medium efficiency


response

Sealed (S)

#### Vented Enclosure

Pros

Vented enclosures use a sealed enclosure with a vent or port in the box which is tuned to resonate at a specific frequency.



Good low frequency extension down to the tuning frequency High power handling down

to the tuning frequency Higher output than sealed


enclosures

Cons Low power handling below the tuning frequency Almost no output below the tuning frequency



## **Bandpass Enclosure**

Bandpass enclosures enclose both sides of the woofer(s). An airtight enclosure is built around the front and back of the woofer and one or both chambers are ported to Sealed Bandpass (SW) specific frequencies.



Vented Bandpass (VBP)

#### Pros


High power handling within the operating frequencies Very high output within the range of the operating frequencies


#### Cons

Low power handling beyond the tuning frequency Poor to moderate transient response Poor low frequency extension


## **Isobaric Woofer Configuration**

There are two basic types of woofer configurations, standard and isobaric. The standard uses a single woofer and is the type used in most subwoofer installations. There are instances, however, when the airspace available for a subwoofer enclosure is not large enough to accommodate a particular design. In these instances, an Isobaric configuration





**Isobaric Vented Bandpass** (ISOVBP)




Isobaric Sealed Bandpass (ISOSBP)

woofer to perform in an enclosure is cut in half. The are disadvantages to the design, however, the main being that even though you are using two woofers, the output is equal to one woofer in an enclosure twice the size of the enclosure for the Isobaricly configured woofer.

## - CALCULATING (NET) INTERNAL ENCLOSURE VOLUMES -


When constructing any type of enclosure, you must be aware that the outside dimensions DO NOT represent the true (Net) volume inside. Such things as woofers, ports, thickness of enclosure material, dividing wall septums, and any internal bracing will reduce the total amount of the

actual air space available. The following worksheet has been designed to provide you with the necessary steps to accurately calculate the absolute (Net) internal volume of any given enclosure.



## **Calculating Cylindrical Port Volume**

- Measure the outside diameter of the port and divide by 2 for the radius.
- 2 Square the radius and multiply by 3.14 (x) to arrive at outside port area.
- 3. Multiply the area by the length of the port inside the enclosure for the port volume.



## BUILDING THE ENCLOSURE

- Determine the dimensions of your enclosure.
- Be certain the box you have designed will fit into the location you have chosen. Sometimes making a cardboard box with the same outside dimensions is helpful.
- Use 3/4 inch thick Medium Density Fiberboard (MDF) or High Density Particleboard. It is preferable to cut the wood with a table saw to ensure straight, even joints. If a table saw is not available, a circular saw is acceptable.
- Use a "T" square to verify precise right angle gluing.
- Use a high quality wood glue and air nails or wood screws to assemble the
  enclosure. Elmer's@ woodworker's glue and Weldwood@ work well. To
  guarantee an airtight box, seal each inside joint with RTV silicone glue.
- For Sealed Enclosures, stuff the chamber with 50-75% filling (approximately 1.5 pounds per cubic foot) of fiberglass insulation or Dacron.
- For Vented Enclosures, staple 1 inch thick fiberglass insulation or Dacron to all walls of the enclosure except the baffle to which the woofer is mounted.
- Use eight(8) wood screws or T-nuts and bolts to secure the woofer.
   Progressively tighten each of the bolts or screws to prevent warping the woofer frame.
- Use slide-on connectors to attach speaker wires (SS-8). Do not solder wires
  to the provided terminals as this may cause damage to the factory wire
  connection. This may also void the speaker's warranty.

## SUGGESTED ENCLOSURES

- The following designs include a variety of enclosure types. Each design has a frequency response curve that shows predicted output with 2.0 volts input, measured at 1 meter. 2.0 volts across a 40hm load corresponds to 1 watt per speaker. Also, each frequency response curve was generated using a 12 dB/octave low pass filter at 100 Hz. The performance of each of these enclosures will be different once installed in a car. The amount each enclosure will vary depends on the car and installation location. The "standard" curves given correspond to performance outside the car to help you visualize relative performance differences. Read through the descriptions given for each enclosure and select the one that suits your needs.
- Remember: all suggested enclosure volumes are Net, and DO NOT include woofer, port, and bracing displacement!


## **REFERENCE** SS8

#### Infinite Baffle

• Excellent performance for all types of music at moderate levels


#### Sealed

- 0.5 ft3 Net Internal Volume Excellent for midbass, must be stuffed with fiberglass or other acoustic insulation
- 100 55 66 57 70 65 60 20 50 100 Frequency (Hz) 500 Seeled (S)
- 1.0.ft3 Good enclosure for classical & jazz




#### Vented

- 0.75 ft<sup>3</sup> @ 35 Hz (3" x 14.5" port) Very good for rock and rap
- 1.0 ft<sup>3</sup> @ 35 Hz (3" x 10.25" port) Very good for jazz and rock, good for classical, good for rap



#### **Vented Bandpass**


• Enclosure #19 - Very high output, smooth response, very good for rap & rock
Rear = 0.86 ft @ 37 Hz (3" x 10.75" port)
Front = 0.39 ft @ 70 Hz (3" x 5.75" port)



## Vented Bandpass - Isobaric Configuration


• Enclosure #19 - High output, wide response, punchy bass, good all around enclosure

Rear =  $0.45 \text{ ft}^3$  @ 35 Hz (3" x 26" port) Front =  $0.2 \text{ ft}^3$  @ 70 Hz (3" x 13.5" port)




## **Sealed Bandpass**

Enclosure #21- Good output, good all around enclosure
 Rear = 0.64 ft<sup>3</sup> sealed
 Front = 0.4 ft<sup>3</sup> @ 65 Hz (4" x 13.25" port)



## Sealed Bandpass - Isobaric Configuration

 Enclosure #23 - Very high output, very good for rap or rock
 Rear = 0.35 ft3 sealed
 Front = 0.4 ft3 @ 65 Hz (4" x 33.25" port)




#### REFERENCE SS10R

#### Infinite Baffle

• Excellent performance for all types of music at moderate levels


#### Sealed

 0.5 ft3 to 1.5 ft3 - Good all around enclosures, very good for classical and jazz, good for rock




#### Vented

 0.75 ft3 @ 37 Hz (3" x 12.75" port) - Good small enclosure




• 1.0 ft<sup>3</sup> @ 35 Hz (3" x 10" port) - Very good all around enclosure




 1.25 ft<sup>3</sup> @ 32 Hz(3" x 9.75" port) - Very good low frequency extension, very good for jazz and rock

#### **Vented Bandpass**


Enclosure #34 - Super high output, very good for rap and rock
 Rear = 1.0 ft<sup>3</sup> @ 47 Hz (4" x 9.25" port)
 Front = 0.85 ft<sup>3</sup> @ 80 Hz (two 4" x 6.5" or three 4" x 10.75" ports)



Enclosure #35 - High output, very good for rap and rock
 Rear = 1.1 ft³ @ 39 Hz (4" x 13.5" port)
 Front = 0.73 ft² @ 73 Hz (two 4" x 10.5" ports)




 Enclosure #36 - Good all-around enclosure Rear = 1.3 ft<sup>3</sup> @ 30 Hz (3" x 11" port) Front = 0.62 ft<sup>3</sup> @ 67 Hz (two 3" x 8.25" ports)



## Sealed Bandpass


Enclosure #31- Very high output, very good for rap
 Rear = 1 .O ft<sup>3</sup> sealed
 Front = 1 .O ft<sup>3</sup> @ 58 Hz (6" x 13.75" or two
 4" x 12.75" or three 3" x 10" ports)



## REFERENCE SS10R (con tinued)


• Enclosure #32 - Very high output for rap or rock

Rear = 1.2 ft<sup>3</sup> sealed Front =  $0.7 \text{ ft}^3 @ 75 \text{ Hz (two 4" x 10.75")}$ ports)



• Enclosure #33 - Good output for all types of music

Rear = 1.8 ft<sup>3</sup> sealed Front =  $1.0 \text{ ft}^3$  @ 50 Hz (4" x 8" or two 3" x 9.5" ports)




#### **REFERENCE SS1 2R**

#### Infinite Baffle

• Excellent performance for all types of music at moderate levels


#### Sealed

• 2.0 ft<sup>3</sup> - Good, smooth butterworth response a 85 (Q=.7), very good for jazz & classical, good for rock



#### Vented

. 4.3 ft<sup>3</sup> @ 30 Hz (two 4" x 11" ports) - Good for jazz & classical, very good for home use



. 3.0 ft<sup>3</sup> @ 30 Hz (4" x 7" port) - Good for rock, good all around enclosure


## **Vented Bandpass**


• Enclosure #40 - Super high output, good for rap or rock


Rear = 2.2  $ft^3$  @ 41 Hz (two 4" x II" ports) Front = 1.9 ft<sup>3</sup> @ 79 Hz (four 4" x 4. l" ports)

• Enclosure #41 - Very high output, good for rap or rock Rear =  $2.4 \text{ ft}^3$  @ 33 Hz (4" x 7.4" port) Front = 1.7  $\mathbf{ft}^3$  @ 72 Hz (three 4" x 4.2" ports)

• Enclosure #42 - High output, good for rap, rock or pop Rear = 3.0 ft<sup>3</sup> @ 28 Hz (4" x 8.6" port) Front = 1.4  $\text{ft}^3$  @ 67 Hz (four 4" x 11.5" ports)








## REFERENCE SS12R (continued)

## **Sealed Bandpass**


ports)


• Enclosure #37 - Very high output, very good

Rear = 1.0 ft<sup>3</sup> sealed Front = 1.5 ft<sup>3</sup> @ 78 Hz (two 6" x 7.4" or three 4" x 5" ports)



Front =  $2.0 \text{ ft}^3 @ 65 \text{ Hz} (8" \times 6.5" \text{ or three 4"})$ x 5.25" ports)





## **Sealed Bandpass - Isobaric Configuration**

• Enclosure #39 - Very high output with good bass extension Rear = 1.0 ft3 sealed Front = 1.5  $\mathbf{ft}^3$  @ 65 Hz (6" x 5" or two 6" x 13.5" or two 4" x 4.75" or three 4" x 8.75"

